


## Пункт: Определение функции панели V-TCR



- |                          |                           |
|--------------------------|---------------------------|
| 1. Touch screen          | 8. Disc window            |
| 2. GPS card port         | 9. Disc window            |
| 3. Sound effect setting  | 10. Right knob            |
| 4. Navigation button     | 11. Eject button          |
| 5. Power button          | 12. Up-selection button   |
| 6. Left knob             | 13. Down-selection button |
| 7. Remote control window | 14. USB cover             |

Notes: copy a upgraded software to SD card, insert it into the GPS card port, then the screen will appear letters to tell you how to do.

# Схема подключения

